



SCALE: NTS

INSTALLATION INSTRUCTIONS:

1. CLEAN AND DRY THE EXTERIOR SURFACES OF THE CASTING, ADJUSTING RINGS, AND STRUCTURE TO BE WRAPPED. SURFACES AND MATERIALS SHALL BE ABOVE 32 DEGREES.
2. APPLY MANUFACTURER RECOMMENDED AEROSOL ADHESIVE OR EZ-PRIMER #4 TO ALL SURFACES TO BE WRAPPED. EZ-PRIMER SHALL BE APPLIED USING A CLEAN PAINT BRUSH OR ROLLER.
3. WAIT FOR SOLVENTS TO DISPENSE FROM THE TREATED SURFACE. EZ-PRIMER TREATED SURFACE SHALL BE DRY AND APPEAR SMOOTH AND CLEAN. AEROSOL ADHESIVE SHALL BE TACKY. DEPENDING ON THE TEMPERATURE THIS MAY TAKE 10-30 MINUTES FOR EZ-PRIMER OR 1-3 MINUTES FOR AEROSOL ADHESIVE.
4. CUT EZ-WRAP TO LENGTH. CUT ENDS SHALL OVERLAP A MINIMUM OF 6".
5. BEGINNING AT THE BOTTOM OF THE STRUCTURE CAREFULLY INSTALL THE EZ-WRAP TO THE DRY, TREATED SURFACES, REMOVING THE RELEASE PAPER AS YOU APPLY THE EZ-WRAP. DO NOT STRETCH THE EZ-WRAP. PRESS THE EZ-WRAP DOWN FIRMLY AND EVENLY AS YOU COVER THE SURFACES.
6. INSTALL EZ-PRIMER OR AEROSOL ADHESIVE OVER TOP 2-INCHES OF EZ-WRAP AND CUT END TO BE OVERLAID. ALLOW SURFACE TO DRY AS STATED IN STEP 3.
7. INSTALL NEXT SECTION OF EZ-WRAP. OVERLAP THE EZ-WRAP VERTICALLY A MINIMUM OF 2-INCHES. DO NOT STRETCH THE EZ-WRAP. PRESS THE EZ-WRAP DOWN FIRMLY AND EVENLY AS YOU COVER THE SURFACES.
8. REPEAT STEPS 6 AND 7 UNTIL THE ENTIRE CHIMNEY SECTION IS WRAPPED.

CHIMNEY SEAL DETAIL

DETAIL: CS - 1

DATE: 7-11-17

APPROVED BY: MATT FINEOUR

VILLAGE OF PLEASANT PRAIRIE
KENOSHA COUNTY, WISCONSIN