



PLAN VIEW

SECTION VIEW

NOTES:

1. REFER TO SPECIFICATIONS FOR TRACER WIRE.
2. TRACER WIRE SHALL BE TAPED TO MAIN, LEAD AND HYDRANT. WIRE IS SHOWN OFF PIPES FOR CLARITY.
3. INSTALL GROUNDING ANODE BY DRIVING INTO VIRGIN GROUND AT THE HYDRANT SHOE.
4. TRACER WIRE ACCESS BOX SHALL BE INSTALLED DIRECTLY BEHIND ALL FIRE HYDRANTS.

SCALE: NTS

TRACER WIRE INSTALLATION ON FIRE HYDRANT		DETAIL: TW - 4
DATE: 12-17-18	VILLAGE OF PLEASANT PRAIRIE KENOSHA COUNTY, WISCONSIN	
APPROVED BY: MATT FINEOUR		